

1-1/4" reducer 8" Extension with 2" riser

Installation Instructions 6-20 v.4



5/8 x 3" Bolt with lock washer and nut
use to attach the 2" receiver base of your
Garbage Hook securely to the new extension

White rear spacer

2" riser

TOP VIEW : Use the 2) 1/4" x 3" bolts and insert them
Thru both holes with the white spacer in the rear of the riser

BOTTOM VIEW: Use the 2) lock washer and nuts
to secure the components together tightly.

Warnings:

- Keep all nuts tightened
 - Do Not exceed 15 MPH, or 150 lbs.
 - Do Not carry passengers
 - Do Not use on public roads
- Turn off vehicle and put in park before attaching your Garbage Hook.

****Garbage Hooks are designed for towing,
DO NOT backup with cans attached. Damage may accrue****

Thank you for your order, as a small company we truly appreciate your business!

*If you have any questions or concerns with your order, text us at 608-607-2788
or send an email to - info@garbagecommander.com*

*Before leaving a negative review, contact us, we promise to make things right with you.
*Help us grow by spreading the word and taking the time to leave a positive review.**



Garbage Commander by:
LaMalco LLC – PO Box 2812 Janesville, WI. 53547-2812
Garbage Hooks are patented and made in the USA.
Patent US 9,789,741 B1

